

### MultiVision Quick Reference Card

Operation	Procedure
Turn on	Press MODE and release.
Turn off	Press and hold MODE until display says "release button" and release.
Auto Cal	Turn MultiVision on. In fresh air press MODE 3 times fast to enter "Auto Cal Mode." Press MODE again to do auto fresh air zero. When complete press MODE again to do auto span. Attach calibration adaptor and flow span gas. Remove fittings when complete.

16JAN2006 p/n 13-232 Version 2.0

  
A Bacou-Dalloz Company

<b>Use hand aspirated sample draw kit</b>	<b>Test for leakage before every use:</b> Attach sample draw kit to instrument. Hold finger over end of probe. Squeeze bulb. Bulb should stay deflated until finger is removed.
	<b>Use:</b> Squeeze bulb 1 time per foot of sample hose. Continue squeezing for 1 add'l minute or until readings stabilize.
<b>Use built-in continuous sample pump</b>	<b>Start:</b> Slip pump adapter onto instrument to start pump. Perform leak test by holding finger over end of probe. Pump should stop. Remove finger and instrument will reset.
	<b>Use:</b> Allow 1 second per foot of sample hose plus 1 additional minute. Continue until readings stabilize.