



Quick Reference Card

ON	<p>Press the MODE button once while the ToxiPro is turned off. All segments in the display will be briefly shown followed by the software version and the sensor type. Datalogging units will show “dL” prior to the sensor type. Version and sensor type shown are only examples!</p>	
	<p>The warning alarm level will be shown and the alarm will sound. Alarm level shown is only an example!</p>	
	<p>The danger alarm level will be shown and the alarm will sound. Alarm level shown is only an example!</p>	
	<p>The ToxiPro is ready for use when the gas reading screen is displayed. Reading shown is only an example!</p>	
FUNCTIONS	<p>Press MODE once to activate the backlight. Press MODE repeatedly to scroll through the MAX, time, STEL (if enabled) and TWA (if enabled) screens.</p>	
	<p>Press and hold MODE until OFF is displayed, then release. The display will then go blank.</p>	

See Reverse for One-Button Auto Calibration

FRESH AIR CAL	Press MODE three times quickly to initiate the auto-cal sequence.	CAL
	Press MODE before the countdown finishes to begin fresh air cal. THE ToxiPro MUST BE IN FRESH AIR.	5 0-CAL
	The unit will alternately display “0” on the left and right sides of the screen with “0-Cal” icon. 3 short beeps will sound upon completion.	0 ↔ 0 0-CAL
SPAN CAL	When 0-Cal is done, the span cal () countdown will start (Toxi Pro Only). Press MODE before the countdown finishes to begin the span cal. “0” screens will alternate.	5 0-CAL
		0 ↔ 0 0-CAL
APPLY GAS	If MODE is pressed, apply gas. Screen will alternate between GAS and the expected calibration gas value. Press MODE again to cancel. Timeout = 60 seconds. Calibration gas value is only an example.	GAS 25
COMPLETE	When gas is detected, the current reading will be displayed (in  mode) as it stabilizes. When calibration is complete, 3 short beeps will sound and the calibration value will be displayed followed by the Max Span value. Readings and calibration values shown are only examples!	22 0-CAL
		25 0-CAL
		92 0-CAL

Please refer to the ToxiPro reference manual for complete instructions